Newland

NLS-HR100
Hand-held 1D Barcode Scanner
User Guide

Version 1.0

Revisions

Version	Description	Date
Pre-release	Initial release	26-08-2009
Version 1.0	Support as from HR100 firmware Version 1.21.21 and higher.	20-05-2010

Disclaimer

© 1999-2008 by Newland Auto-ID Tech. Co., Ltd, All rights reserved.
No part of this publication may be reproduced, transmitted, or used in any form or by any means, electrical or mechanical, without prior written permission from Newland Auto-ID. The material in this manual is subject to change without notice.

All software, including firmware, is provided strictly on an “as is” basis and is provided without further warranty. Newland Auto-ID grants to the user a non-transferable and non-exclusive license to use each software or firmware program delivered hereunder (licensed program). Except as noted below, such license may not be assigned, sublicensed, or otherwise transferred by the user without prior written consent of Newland Auto-ID. No right to copy a licensed program in whole or in part is granted except as permitted under copyright law or as hereinafter expressly provided. The user agrees to maintain Newland Auto-ID’s copyright notice on the licensed programs delivered hereunder, and to include the same on any authorized copies it makes in whole or in part. The user agrees not to decompile, disassemble, decode, or reverse engineer any licensed program or product delivered to the user or any portion thereof.

Newland Auto-ID reserves the right to make changes and improvements to any software or product for reliability, function, or design.

Newland Auto-ID does not assume any responsibility or liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

No license is granted, either expressly or implicitly, estoppels, or otherwise under any Newland Auto-ID intellectual property rights. An implied license only exists for equipment, circuits, and subsystems contained in Newland Auto-ID products.

Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation. All other product or service names are the property of their respective owners.

Newland Auto-ID Tech. Co., Ltd,

Content

About this guide

Introduction 1
Chapter Description 1
Graphic Notations 2
Newland Auto-ID Support Center 2

Getting to Start

Introduction 3
Unpacking 4
  Unpacking 4
  Outline of HR100 4
  Data Interface 5
Communication Ports 6
Connecting with USB Cable 7
Connecting with RS232 Cable 8
Connecting with PS/2 Cable 9
Removal of Communication Cable 10
ON, OFF, IDLE, RESTART 11
Maintenance 11
Reading 12
Decode Zones 13
Specifications 14
Dimensions of HR100 Unit 15
  HR100 Left View 15
  HR100 Front View 15
  HR100 Top View 15

General Programming

Introduction 16
  Code Programming 16
  Command Programming 16
Programming Notation 17
Code Programming 18
Command Programming 19
Default 21
  Factory Default 21
Working Mode 22
Reading Mode 23
  Hand-held Mode 23
  Auto Mode 24
  Interval Mode 25
  Sensor Mode 26
  Continuous Mode 27
  Delayed Sensor Mode 28
  Command Triggered Mode 29

Security Level 30
Beeper 31
Others 32
Start/Stop Analog Trigger 32
Start/Stop Temporary Mute 32

Query Command

Introduction 33

Communication Programming

Introduction 34
Serial Port Programming 35
Baud Rate 35
Check 36
Stop Bit 37
Flow Control 38
Data Bit 39
USB Programming 41
USB Virtual Keyboard 41
USB COM Port Emulation 41
USB Virtual Keyboard & PS/2 Keyboard Programming 42
Keyboard Layout 42
USB Virtual Keyboard & PS/2 Keyboard Programming 43
Character Delay 43
Character Conversion 43
Function Key 44

Data Format

Introduction 45
Prefix Sequences 46
User Prefix 47
Disable or Enable User Prefix 47
Program User Prefix 47
AIM Prefix 48
Code ID Prefix 49
User Suffix 50
Disable or Enable User Suffix 50
Program User Suffix 50
Terminal 51
Disable or Enable Terminal 51
Program Terminal 51

Symbols

Introduction 52
Code 128 53
Load Factory Default 53
Enable/Disable Code 128 53
Code 128 Code ID 53
Select Message Length 54
UCC/EAN-128 55
Load Factory Default 55
Enable/Disable UCC/EAN-128 55
UCC/EAN-128 Code ID 55
Select Message Length 56
AIM 128 57
Load Factory Default 57
Enable/Disable AIM 128 57
AIM 128 Code ID 57
Select Message Length 58
EAN-8 59
Load Factory Default 59
Enable/Disable EAN-8 59
EAN-8 Code ID 59
2 Digits Addenda Code 60
5 Digits Addenda Code 60
EAN-8 expand to EAN-13 61
Check Digit 61
EAN-13 62
Load Factory Default 62
Disable/Enable EAN-13 62
Check Digit 63
EAN-13 Code ID 63
2 Digits Addenda Code 64
5 Digits Addenda Code 64
ISSN 65
Load Factory Default 65
Enable/Disable ISSN 65
ISSN Code ID 65
ISBN 66
Load Factory Default 66
Enable/Disable ISBN 66
ISBN Digits 67
ISBN Code ID 67
UPC-E 68
Load Factory Default 68
Disable/Enable UPC-E 68
Check Digit 69
UPC-E Code ID 69
2 Digits Addenda Code 70
5 Digits Addenda Code 70

Transmit Default “0” 71
UPC-E Expand to UPC-A 71
UPC-A 72
Load Factory Default 72
Disable/Enable UPC-A 72
UPC-A Code ID 72
Check Digit 73
Transmit Default “0” 73
2 Digits Addenda Code 74
5 Digits Addenda Code 74
Interleaved 2 of 5 75
Load Factory Default 75
Disable/Enable Interleaved 2 of 5 75
Interleaved 2 of 5 Code ID 75
Check Digit 76
Select Message Length 77
ITF-6 78
ITF-6 Code ID 78
ITF-14 79
ITF-14 Code ID 79
Deutshe14 80
Load Factory Default 80
Disable/Enable Deutshe14 80
Deutshe14 Code ID 80
Deutshe12 81
Load Factory Default 81
Disable/Enable Deutshe12 81
Deutshe12 Code ID 81
COOP25（Japanese Matrix 25） 82
Load Factory Default 82
Enable/ Disable COOP25 82
COOP25（Japanese Matrix 25） Code ID 82
Check Digit 83
Select Message Length 84
Matrix 25(European Matrix 25) 85
Load Factory Default 85
Enable/ Disable Matrix 25 85
Matrix 25 Code ID 85
Check Digit 86
Select Message Length 87
Industrial 25 88
Load Factory Default 88
Enable/ Disable Industrial 25 88
Industrial 25 Code ID 88
Check Digit 89
Select Message Length 90
Standard 25 91
Load Factory Default 91
Enable/ Disable Standard 25 91

Standard 25 Code ID 91
Check Digit 92
Select Message Length 93
Code 39 94
Load Factory Default 94
Enable/Disable Code 39 94
Code 39 Code ID 94
Check Digit 95
Transmit Start & Stop Character 96
Decode ASCII 96
Select Message Length 97
Codabar 98
Load Factory Default 98
Enable/Disable Codabar 98
Codabar Code ID 98
Check Digit 99
Transmit Start & Stop Character 100
Select Message Length 101
Code 93 102
Load Factory Default 102
Enable /Disable Code 93 102
Code 93 Code ID 102
Check Digit 103
Select Message Length 104
Code 11 105
Load Factory Default 105
Enable/ Disable Code 11 105
Code 11 Code ID 105
Check Digit 106
Select Message Length 107
Plessey 108
Load Factory Default 108
Enable/ Disable Plessey 108
Plessey Code ID 108
Check Digit 109
Select Message Length 110
MSI-Plessey 111
Load Factory Default 111
Enable/ Disable MSI-Plessey 111
MSI-Plessey Code ID 111
Check Digit 112
Select Message Length 113
GS1 Databar 114
Load Factory Default 114
Enable/ Disable GS1 Databar 114
GS1 Databar Code ID 114

Appendix

Factory Default List *115*
AIM ID List *121*
Code ID List *122*
Digit Code *123*
Save and Abort *125*

About this guide

Introduction

This NLS-HR100 (“HR100”) Barcode Scanner User Guide provides general instructions for how to use it .

Chapter Description

Getting to Start: The chapter of Getting to Start gives a brief description of the HR100. It covers the general, overall specifications of the HR100.

General Programming: The chapter of General Programming describes the general methods to program HR100. There are two methods respectively Code Programming and Command Programming.

Query Command: The chapter of Query Command describes how to query related information of HR100 by reading programming codes.

Communication Programming: The chapter of Communication Programming describes the serial port programming and KBW programming.

Data Format: The chapter of Data Format describes how to use Prefix and Suffix to fullfill users' needs in more information of the barcodes.

Symbols, lists all the available symbols and provides the parameters supported by the HR100.

Graphic Notations

Tool – Handy item for a task.

Attention – Important subject to be aware of or to avoid.

Tips – Helpful information about a topic or a feature.

Example – Illustration of how to use a feature.

Newland Auto-ID Support Center

If you have a problem with your equipment, contact the Newland Support Center in your region. Before calling, have the model number, serial number, and several of your barcodes at hand.

Call the support Center from a phone near the scanning equipment so that the service person can try to talk you through your problem. If the equipment is found to be working properly and the problem is barcode readability, the Support Center will request samples of your bar codes for analysis at our plant.

If your problem cannot be solved over the phone, you may need to return your equipment for servicing. If that is necessary, you will be given specific directions.

Note: Newland Auto-ID Tech. is not responsible for any damages incurred during shipment.

For service information, warranty information or technical assistance contact or call the Support Center listed below. For the latest service information go to http://www.nlscan.com

If you purchased your Newland product from a Newland Business Partner, contact that Business Partner for Service.

Getting to Start

Introduction

HR100 is a 1D barcode reader. Newland Auto-ID patented UIMG™ technology ensure HR100 fast image capture and accurate decoding. It provides the customer the best value.

HR100 can be used as a hand-held reader. Ergonomically designed to provide comfortable and easy use.

This chapter presents an overall picture of how to use HR100 step by step. Please have an HR100 handy.

This chapter is recommended to general users, maintenance personnel, and software programmers.

Unpacking

Unpack HR100 and accessories. Check with the packing list. Make sure that there is no damage or missing part(s). If any damage or missing parts, please keep the original package and contact your supplier for services.

Outline of HR100

The figure below shows major components of HR100.



HR100 Outline

Indicator Lights：

» When power on, the red light will be on for two seconds and then off.

» When read a barcode successfully, the green light wil be on for two seconds and then off. If there are more than one barcodes read in one second, the green light which indicates the first successful reading will be off when the second barcode is read successfully. And then the green light which indicates the second successful reading will be on.

Data Interface



Pin	Function	Type	Name
1	CLK1	IO	Keyboard Clock Signal
2	DATA1	IO	Keyboard Data Signal
3	VCC	P	Power DC5V
4	TXD	O	Serial Port Output，RS232
5	RXD	I	Serial Port Input，RS232
6	CLK2	IO	PC Clock Signal
7	DATA2	IO	PC Data Signal
8	GND	P	Ground
9	D-	IO	USB Data Signal
10	D+	IO	

Communication Ports

HR100 must connect to a Host to operate. A Host can be PC, POS, or any intelligent terminal with at least one of the following communication ports: USB, RS232, or PS/2.

1、USB

USB port on Host：



2、RS232

RS232 port on Host：

3、PS/2

PS/2 port on Host：

Please check the ports first to order the fitting cable.

Connecting with USB Cable



1、Insert USB Cable (RJ45 male head) into HR100 cable slot;

2、Insert USB Cable (USB male head) into Host’s (female) USB connector;

Connecting with RS232 Cable



1、Insert RS232 cable (RJ45 male head) into HR100 cable slot;

2、Insert RS232 cable (RS232 male head) into Host’s (female) RS232 connector;

3、Connect RS232 cable and the mains with power adapter;

Connecting with PS/2 Cable



1、Insert PS/2 cable (RJ 45 male DIN) into HR100 cable slot;

2、Insert PS/2 cable (PS/2 male DIN) into Host PS/2 female slot;

3、If necessary, connect PS/2 cable and the mains with power adapter;

4、If necessary, keyboard can connect to female slot on the PS/2 cable;

Removal of Communication Cable



A Pin that fit the HR100 “Dismount hole” is needed. A paper clip could be ideal. Stretch one end of the paper clip to fit the “Dismount Hole”. Follow the steps:

1、For RS232 and PS/2 connections, unplug the power adaptor.

2、Insert the Pin into “Dismount Hole” and keep some pressure.

3、Pull out the cable gently.

4、Pull out the Pin after the cable is removed.

5、Unplug the connector from the Host.

ON, OFF, IDLE, RESTART

Power On

Connect HR100 and Host. One click the "Trigger". HR100 powers on and in "Idle" (ready to use) state (factory default).

Power Off

There are 4 ways to "Power OFF":

- Remove Cable Off HR100;
- Remove Power Adapter Off RS232 Cable;
- Remove USB Cable Off the Host;
- Remove PS/2 cable off the Host and power adaptor.

IDLE

When reader is NOT reading, it is in "IDLE mode".

No reading attempt within a timeout, the Imager switch to IDLE mode automatically.

RESTART

If HR100 halted and does not respond to operations, please "Restart" by "Power OFF", and then "Power ON".

Maintenance

- The scan window must be kept clean. Improper maintenance will breach the limited warranty.
- Avoid rough objects not to damage or scratch the window.
- Use brush to remove the stain.
- Use soft cloth (cloth for glasses) to clean.
- Prohibit spraying towards the window.
- Only use clean water as a cleanser.

1、Ensure HR100, cables, and the Host are connected, then turn the unit Power ON

2、Press & hold Trigger. Illumination LED cast an Illumination Pattern (red light line) ;

3、Keep Illumination Pattern in the center of a bar code. Zoom in and zoom out to allocate the Optimum Reading Stance.

4、On a successful reading, there’ ll be a beep sound, illumination die out. The HR100 then transmits barcode message to the Host.

NOTE: Experiences tell a certain range of distances has higher successful reading rate. This range is the Optimum Reading Stance.



Decode Zones



Specifications

Performance		
Image Sensor		Linear CCD
Interface		USB-HID, True RS232, TTL level RS232, Keyboard Wedge
Resoluing		2500
Decoded Speed		200/s
Symbologies		Code128, EAN-13, EAN-8, Code39,UPC-A, UPC-E, Codabar, GS1 Databar, Interleaved 2 of 5, ISBN/ISSN, Code 93, etc.
Precision		≥ 5mil
Light Source		Visible LED Diode 620 nm
Depth of Scan Field		Code 39（10mil）:25-280; Code 39（15mil）:20-390; ENA-13 （10mil）:45-230; ENA-13 （15mil）:30-375; Code128（10mil）:30-300; Code128（15mil）:25-380;
Print Contrast Signal		≥ 30%
Sensitivity**	Pitch	±60° @ 0° Roll and 0° Skew
	Roll	±30° @ 0° Pitch and 0° Skew
	Yaw	±75° @ 0° Roll and 0° Pitch
Illumination		0 ~ 100,000 LUX
Mechanical/ Electrical		
Power Consumption		0.75W (Max)
Voltage		DC 5.0V
Current	Peak	150mA
	Operat.	120mA
	Idle	45mA
Colours		Black OR White
Weight		105g
Environment		
Operate Temperature		-0℃ to + 50℃
Storage Temperature		-40℃ to + 60℃
Humidity		0 to 95% relative humidity(non-condensing)

Certifications

FCC Part15 Class B, CE EMC Class B

**Test Condition:
Code39: 3 Bytes ; Resolution = 10mil; W:N = 2.5:1 ; PCS = 0.8 ;
Barcode Height = 11mm; Distance = 120mm; T=23° C; Illumination= 200 LUX

HR100 Left View

The figure 1 HR100 Left View has the height dimensions.



Unit：mm

Figure 1. HR100 Front View

HR100 Front View

The Figure 2 HR100 Front View has the length dimensions of scan window and handle.



Unit：mm

Figure 2. HR100 Right Side View

HR100 Top View

The figure 3 HR100 Top View has the width and length dimentions of the head.



Unit：mm

Figure 3. HR100 Top View

General Programming

Introduction

There are 2 ways to program (configure) the Engine, Code Programming and Command Programming.

Code Programming

The Engine reads a set of specially encoded barcodes to program options and features. In the following sections, we will explain the options and features available and provide the barcodes to program them.

This method of programming the Engine is most straight forward. However, it requires manually readings of each barcode. As all manual operations, errors are more likely to occur.

Command Programming

The Host can send the Pro CMD strings to program the Engine. In the following sections, the Pro CMD strings will be included with the barcodes for Code Programming.

This method of programming the Engine could be automated. A software program can be developed to download all the configuration data to the Engine. The program can also verify the download.

Note: Except some temporary programming, the programming results are restored in non-volatile memory. They will not be lost when the Engine is powered off.

Programming Notation

Tools

Code Programming ON

Code Programming OFF

This is the notation to disable the Code Programming.

There are 3 parts of a notation:

1、The barcode for Code Programming

2、The name of the options or features, such as Disable Code Programming.

3、The corresponding Pro CMD string of the Code Programming.

Tools

Code Programming ON

Code Programming OFF

Read the “Code Programming ON” barcode to activate “Code Programming” function. More than one Code Programming barcodes can be read to configure the Engine.
If an option or feature needs additional parameters, such as digits, they can be found at the end of this chapter.
The value of code programming can be sent to the Host. For factory default, “No Send Pro Code Value”, the value of programming codes will not be sent to the Host; by reading “Send Pro Code Value”, the reader will send the value of Programming Code to the Host.

The factory default setting is “Code Programming ON”. Because it has low probability that a data barcode is the same as a programming barcode, it doesn’t need to close the function of Code Programming. Keeping it on won’t affect the daily using.

Some working parameters could be programmed. The data type of parameters is Dec or Hex and the numbers are also input through programming barcodes. The Appendix of the Integration Guide includes all needed data barcodes.

Programming barcodes are used to program the engine. For factory default, the reader will not send code value to the Host. But if needed, the engine could be programmed to "Send Pro Code Value". And whether the value is sent or not won't affect the programming function. But "Send Pro Code Value" is a temporary setting. It will restore to "No Send Pro Code Value" when the engine is restarted or closed.

Code Programming ON
【Pro CMD：99900031】

Code Programming OFF
【Pro CMD：99900032】

No Send Pro Code Value
【Pro CMD：99900033】

Send Pro Code Value
【Pro CMD：99900034】

Commands under RS232 connection mean using 0x20-0x7D（the displayable characters）to express all commands information.

1、Configuration State

The engine should be in configuration state when programming functions under RS232 connection. In the state, the engine would only accept and execute the commands from communication and feed back.

Sending certain command to the engine will make it enter or quit the configuration state. Or if in configuration state the engine hasn’t received new information for five seconds, the engine will quit the state automatically.

2、Express Regulation

①、Sending “$$$$” and receiving “@@@@” mean entering configuration state successfully.

②、Sending “%%%%” and receiving “^^^^” mean quitting configuration state successfully.

③、Receiving “^^^^” in configuration state means that the engine has quitted the state automatically.

④、In configuration state, every command begins with “#” and ends with “;”.E.g. “#99900030;”

⑤、 In configuration state, if the command is executed successfully, the Host will receive a command which begins with “!” and ends with “;”. E.g. “!99900030;”。

⑥、 In configuration state, if the command is invalid or executed unsuccessfully, the Host will receive a command which begins with “?” and ends with “;” E.g. “?99976543;”

⑦、In configuration state, if commands of query type are executed successfully, the host will receive “! xxxxxxxx；” as well as the feedback which begins with “&{“ and ends with “|”. In the last nine characters in feedback, such as “|BF7974B7”, “|” is the separating character which separates the feedback information and check value. And other eight characters “BF7974B7” are CRC32’s Hex value and arranged from the highest position to the lowest. The feedback information is placed between “{“ and “|”. E.g.: Sending “#99900301;” and receiving “!99900301;&{Firmware v1.7.5;Decoder v1.00.023.C6;|FD25430B}”

If feedback information may have undisplayable characters, it will be expressed in hexadecimal notation. Two characters represent a character value. E.g.

“&{AAAA100423C5008001FF400001FF400001FF400001FF400001FF4000000040800000
40800000400000004080000040800000408006FF40000000408000004080000040800000408006F
FF400006FF400006FF400006FF400004FF400004FF400002FF400004FF400004FF400004F
F400001FF4000000000006A75667467646E426863657271776C6F7669736261797A706D5-
2000000000000000000000000000000000000000000000000000000000000000000600000FEB2A2F4CC
CFD390ADC8D38FF5E6D99DAA|E1DFA587}”

⑧、In configuration state, if a command is with parameters, it will be composed following the rules which command system defined. For example, the command string which has 0x0D and 0x0A as ending character and be saved is “#99904112;#99900000;#99900015;#99900000;#99900012;#99900020;”。

3、Flow Chart


Host sends “$$$$” and receives “@@@@”
Non-Configuration State
5 seconds timeout, receives “^^^^”
Host sends “%%%%” and receives “^^^^”
Configuration State
Host sends commands, such as “#XXXX;”
Executing Commands
Unsuccessful
Receives feedback which begins with “?” and ends with “;”
Successful
Is it a query command?
No
Receives feedback which begins with “!” and ends with “;”
Yes
Receives feedback which begins with “?” and ends with “;”
Receives query information which begins with “&{” and ends with “}”

Code Programming ON

Code Programming OFF

Factory Default

Read “Load All Factory Default” to reset all parameters to factory default.

Applicable conditions:

» User options programming wrong configuration leads to reading malfunction

» Forget details of previous programming and start over.

» Restore to default after unusual settings are not needed.

Load All Factory Default
【Pro CMD：99900030】

Tools

Code Programming ON

Code Programming OFF

Shut Down[1]
【Pro CMD：99900100】

Deep Sleep[2]
【Pro CMD：99900101】

Sleep[3]
【Pro CMD：99900102】

Test Mode[4]
【Pro CMD：99900103】

Restart
【Pro CMD：99900104】

Note:

1、The engine couldn't be awaked. It must restart or power on.

2、It should be awaked by a trigger.

3、It could be awaked by communication or a trigger.

4、 Use a trigger to quit test mode.

TIPS

All these five modes are temporary. They will disappear and restore to former mode if the engine restarts or powers off.

Code Programming ON

Code Programming OFF

Hand-held Mode

Factory Default, scan engine will begin to scan when triggered. And when it scans successfully or the trigger is released, the engine will stop scanning.

Hand-held Mode
【Pro CMD：99900110】

In hand-hald mode, the engine could set Reading a barcode time length.

Reading a barcode time length
【Pro CMD：99900150】

Code Programming ON

Code Programming OFF

Auto Mode

First program the engine, then trigger it, the engine will start to scan. After a scan, the engine will not stop but start a new one automatically until another trigger. By default, the engine will not repeat reading a same barcode.

Auto Mode
【Pro CMD：99900111】

In auto mode, the engine could set Reading a barcode time length, and set if it could read same barcode.

Reading a barcode time length
【Pro CMD：99900150】

Disable Reading Same Barcode
【Pro CMD：99900155】

Restart Timer After a Valid Reading
【Pro CMD：99900157】

Enable Reading Same Barcode
【Pro CMD：99900156】

Do Not Restart Timer After a Valid Reading
【Pro CMD：99900160】

» Reading Same Barcode

When enabled，after a successful read, the engine will not stop but start a new one automatically until another trigger.
When disabled，after a successful read, if the next barcode is the same one, the engine will keep waiting. If the next barcode is different, the engine will not stop but start a new one automatically until another trigger.

» Restart Timer After a Valid Reading

When enabled, after a successful read, the engine will revert the reading time to zero and restart timer.
When disabled, no matter how many barcodes have been read, when the length of reading time is equal to the default value of "Reading a barcode time length", the engine will stop reading.

Interval Mode

Code Programming ON

Code Programming OFF

After programming, the engine will start interval scan without trigger. The interval between two scans is fixed whether the scan is successful or not. The value of interval could be programmed by user and the default value is 1s.

Interval Mode
【Pro CMD：99900112】

Reading a barcode time length
【Pro CMD：99900150】

Interval Length
【Pro CMD：99900151】

Interval takes 500ms as a unit and could be classed in fifteen levels:0-15.For instance, interval could be programmed to 5000ms:

1、Read “Code Programming ON”

2、Read “Interval Length”

3、Read numbers “1” “0”

4、Read “Code Programming OFF”

Code Programming ON

Sensor Mode

Code Programming OFF

After programming, the engine will start to sense the environment without trigger. After a scan, it will stop and keep sensing to wait another illumination changing. In sensor mode, a trigger also can start a scan. The sensitivity level could be chosen.

Sensor Mode
【Pro CMD：99900113】

In sensor mode, the engine could set Reading a barcode time length, and set interval length as sensing stabilization time.

Reading a barcode time length
【Pro CMD：99900150】

Interval Length
【Pro CMD：99900151】

Sensitivity is used to evaluate the engine's ability to sense the changing environment. Users can choose a sensitivity level which suits the environment.

High Sensitivity
【Pro CMD：99900152】

Low Sensitivity
【Pro CMD：99900154】

Medium Sensitivity
【Pro CMD：99900153】

User Sensitivity
【Pro CMD：99900161】

Sensitivity Level Programming
There are sixteen levels of 0 to F. The lower the value is, the higher the sensitivity level is.
For instance, we could program sensitivity level as 5 level.

1、Read "Code Programming ON"

2、Read "User Sensitivity"

3、Read number "5"

4、Read "Code Programming OFF"

Code Programming ON

Continuous Mode

After programming, the engine will be in continuous mode without trigger. After a successful scan，the engine will be in waiting state until another scan, then wait again.

Code Programming OFF

Continuous Mode
【Pro CMD：99900114】

In continuous mode, the engine could set Reading a barcode time length and interval length.

Reading a barcode time length
【Pro CMD：99900150】

Interval Length
【Pro CMD：99900151】

Code Programming ON

Delayed Sensor Mode

After programming, the engine will start to sense the environment without trigger. There will be a delay before a scan. After a scan, it will stop and keep sensing to wait another illumination changing. In delayed sensor mode, a trigger also can start a scan. The sensitivity level could be chosen.

Code Programming OFF

Delayed Sensor Mode
【Pro CMD：99900115】

In delayed sensor mode, the engine could set Reading a barcode time length and interval length.

Reading a barcode time length
【Pro CMD：99900150】

Interval Length
【Pro CMD：99900151】

TIPS

In delayed sensor mode, reading a barcode time takes 2s as a unit and the range is from 0 to 30ms, 0 is infinite time; Interval takes 200ms as unit and the range is from 0 to 7.5s.

Code Programming ON

Code Programming OFF

Command Triggered Mode

After programming, when HR100 receives trigger sweep command from terminal（e.g. PC）, then the device is begun working.
PS: If the scan is completed then should be returned a value and automatic shutdown. Else the scanner would continue to scan till Stop command coming.

When HR100 receives stop command from terminal （e.g. PC）,then the device is stopped. In the meanwhile the device must be returned 2 byte data(e.g. 0A;0B)

Command Triggered Mode
【Pro CMD：99900116】

If a reading is failed, the engine will send a character which means a reading failure. Users could set the character themselves.

Set Reading Failure Character
【Pro CMD：99904200】

Security Level

Tools

Code Programming ON

The higher the value of Security Level is, the lower the probility of mis-decoding and the decoding speed are. Otherwise, the speed is higher.

Code Programming OFF

Security Level 1
【Pro CMD：99900120】

Security Level 3
【Pro CMD：99900122】

Security Level 2
【Pro CMD：99900121】

Security Level 4
【Pro CMD：99900123】

Beeper

Tools

Code Programming ON

Code Programming OFF

No Beeper Output
【Pro CMD：99900130】

High Frequency & Loud Volume
【Pro CMD：99900131】

High Frequency & Medium Volume
【Pro CMD：99900132】

High Frequency & Low Volume
【Pro CMD：99900133】

Medium Frequency & Loud Volume
【Pro CMD：99900134】

Medium Frequency & Medium Volume
【Pro CMD：99900135】

Medium Frequency & Low Volume
【Pro CMD：99900136】

Low Frequency & Loud Volume
【Pro CMD：99900137】

Low Frequency & Medium Volume
【Pro CMD：99900140】

Low Frequency & Low Volume
【Pro CMD：99900141】

150ms Sound Length
【Pro CMD：99900142】

100ms Sound Length
【Pro CMD：99900143】

50ms Sound Length
【Pro CMD：99900144】

Code Programming ON

Code Programming OFF

Start/Stop Analog Trigger

Start Analog Trigger
【Pro CMD：99900035】

StopAnalog Trigger
【Pro CMD：99900036】

Start/Stop Temporary Mute

Start Temporary Mute
【Pro CMD：99900040】

Stop Temporary Mute
【Pro CMD：99900041】

Query Command

Introduction

After reading interrelated programming barcodes, the engine will feed information needed back to the Host to achieve the purpose of query.

Tools

Code Programming ON

Code Programming OFF

Query Product Information
【Pro CMD：99900300】

Query Manufacturing Date
【Pro CMD：99900303】

Query Hardware Version
【Pro CMD：99900301】

Query Product Name
【Pro CMD：99900304】

Query Product ID
【Pro CMD：99900302】

Introduction

Under RS232 connection the engine and the Host use the same communication parameters: baud rate, parity check, data bits select and stop bits select.

Code Programming ON

Baud Rate

Code Programming OFF

Under RS232 connection, the engine and the Host should set communication baud rate to the same to keep normal communication.
Baud rate is the bits transmitted per second (8 bits per bytes). The engine and the Host must communicate at the same baud rate.
The reader supports baud rate as the following:

9600
【Pro CMD：99902104】

1200
【Pro CMD：99902101】

2400
【Pro CMD：99902102】

4800
【Pro CMD：99902103】

14400
【Pro CMD：99902105】

19200
【Pro CMD：99902106】

38400
【Pro CMD：99902107】

57600
【Pro CMD：99902110】

115200
【Pro CMD：99902111】

Code Programming ON

Code Programming OFF

Check

No Check
【Pro CMD：99902120】

Even Check
【Pro CMD：99902122】

Odd Check
【Pro CMD：99902121】

Code Programming ON

Stop Bit

Code Programming OFF

1 Stop Bit
【Pro CMD：99902131】

2 Stop Bit
【Pro CMD：99902133】

Code Programming ON

Flow Control

Code Programming OFF

No Flow Control
【Pro CMD：99902140】

Code Programming ON

Data Bit

Code Programming OFF

8 Data Bit
【Pro CMD：99902150】

8 Data Bit, No Check, 1 Stop Bit
【Pro CMD：99902160】

8 Data Bit, Even Check, 1 Stop Bit
【Pro CMD：99902161】

8 Data Bit, Odd Check, 1 Stop Bit
【Pro CMD：99902162】

8 Data Bit, No Check, 2 Stop Bit
【Pro CMD：99902163】

8 Data Bit, Even Check, 2 Stop Bit
【Pro CMD：99902164】

8 Data Bit, Odd Check, 2 Stop Bit
【Pro CMD：99902165】

Code Programming ON

Code Programming OFF

7 Data Bit
【Pro CMD：99902151】

7 Data Bit, Even Check, 2 Stop Bit
【Pro CMD：99902170】

7 Data Bit, Even Check, 1 Stop Bit
【Pro CMD：99902166】

7 Data Bit, Odd Check, 2 Stop Bit
【Pro CMD：99902171】

7 Data Bit, Odd Check, 1 Stop Bit
【Pro CMD：99902167】

Code Programming ON

Code Programming OFF

USB Virtual Keyboard

USB Virtual Keyboard
【Pro CMD：99902300】

USB COM Port Emulation

USB COM Port Emulation
【Pro CMD：99902301】

Code Programming ON

Code Programming OFF

Keyboard Layout

No. 0 Chinese(Factory Default)
【Pro CMD：99902200】

No.1 American
【Pro CMD：99902201】

No.2 Belgian
【Pro CMD：99902202】

No.3 Danish
【Pro CMD：99902203】

No.4 Finnish
【Pro CMD：99902204】

No.4 French
【Pro CMD：99902205】

No.6 Autrichien,German
【Pro CMD：99902206】

No.7 Italian
【Pro CMD：99902207】

No.8 Norwegian
【Pro CMD：99902210】

No.9 Spanish
【Pro CMD：99902211】

No.10 Swiss
【Pro CMD：99902212】

No.11 English
【Pro CMD：99902213】

Code Programming ON

Code Programming OFF

Character Delay

Character delay time is 0 to 150ms, the default value is 0ms.

Chracter Delay
【Pro CMD：99902220】

Character Conversion

Constant
【Pro CMD：99902230】

All Small
【Pro CMD：99902232】

All Capital
【Pro CMD：99902231】

Reverse
【Pro CMD：99902233】

Code Programming ON

Function Key

Code Programming OFF

Caps Lock
【Pro CMD：99902240】

Nums Unlock
【Pro CMD：99902243】

Caps Unlock
【Pro CMD：99902241】

Scroll Lock
【Pro CMD：99902244】

Nums Lock
【Pro CMD：99902242】

Scroll Unlock
【Pro CMD：99902245】

Data Format

Introduction

1D barcodes could contain digits, letters and symbols, etc. 2D barcodes could contain more data, such as Chinese characters and other multi-byte characters. However, in reality, they do not and should not have enough information we need, such as barcode type, date and time of scan, delimiter, and so on, in order to keep the code short and flexible.

Prefix and Suffix are how to fulfill the needs mentioned above. They can be added, removed, and modified while the original barcode message is still in tact.

Barcode processing sequences: first add Prefix/Suffix, then terminate with Terminal and transmit.

Code Programming ON

Code Programming OFF

CodeID+User Prefix+AIMID
【Pro CMD：99904010】

User Prefix+CodeID+AIMID
【Pro CMD：99904011】

Disable or Enable User Prefix

Code Programming ON

Code Programming OFF

User Prefix is added before barcode message. For example, if the user prefix is “AB” and the barcode message is “123”, the Host receives “AB123”.

Disable User Prefix
【Pro CMD：99904020】

Enable User Prefix
【Pro CMD：99904021】

Program User Prefix

Enable “Program User Prefix”. Then program user prefix byte(s). To end the prefix, read “Save programming” The user prefix byte is programmed in its hex values. See example below.

Program User Prefix
【Pro CMD：99904022】

Example

Program “CODE” as user prefix (The hex of “CODE” are 0x43/0x4F/0x44/0x45):
1. Read “Code Programming ON”
2. Read “Program User Prefix”
3. Read “4,3,4,F,4,4,4,5” in order
4. Read “Save Programming”
5. Read “Code Programming OFF”.
6. Read “Allow User Prefix” to enable above programming. “CODE” will appear to the left of a barcode.

AIM Prefix

Tools

Code Programming ON

Code Programming OFF

AIM (Automatic Identification Manufactures) defines AIM prefix for many standard barcode formats. The engine will add the identifier before the barcodes. And this identifier is the AIM Prefix. And please see Appendix to find the AIM ID list.

No AIM Prefix
【Pro CMD：99904030】

Full Characters Mode
【Pro CMD：99904031】

Code ID Prefix

Tools

Code Programming ON

Code Programming OFF

Besides AIM prefix, Code ID prefix can be used to denote barcode format and can be customized.

The Code ID prefix MUST be one (1) or two(2) visible English letters, capital or small, only.

No Code ID Prefix
【Pro CMD：99904040】

Allow Code ID Prefix
【Pro CMD：99904041】

Load Code ID Factory Default
【Pro CMD：99904042】

Code Programming ON

Disable or Enable User Suffix

User suffix is appended to the right of barcode message. For example, if user suffix is “AB”, and the barcode message is “123”, The Host receives “123AB”.

Code Programming OFF

Disable User Suffix
【Pro CMD：99904100】

Enable User Suffix
【Pro CMD：99904101】

Program User Suffix

Read “Program User Suffix”. Then program user suffix byte(s). To end the suffix, read “Save programming”. The user suffix byte is programmed in its hex values. See example below.

Program User Suffix
【Pro CMD：99904102】

Example

Program “AGE” as user suffix (The hex of “AGE” are0x41/0x47/0x45):
1. Read “Code Programming ON”
2. Read “Program User Suffix”
3. Read “4,1,4,7,4,5” in order
4. Read “Save Programming”
5. Read “Code Programming OFF”
6. Read “Allow User Suffix” to enable above programming. “AGE” will appear to the right of a barcode.

Code Programming ON

Disable or Enable Terminal

Code Programming OFF

"Terminal" is the termination for a string of barcode messages. It is fixed to the right and the very end of a barcode transmission.
The major difference between "Terminal" and "User Suffix" is that the information and the decoded messages in user suffix could be formatted but couldn't in terminal.

Disable Terminal
【Pro CMD：99904110】

Enable Terminal
【Pro CMD：99904111】

Program Terminal

Read "Program Terminal". Then program terminal byte(s). At last, read "Save programming". The terminal byte is programmed in its hex values. See example below.

Set Terminal as 0x0D and Enable Sending
【Pro CMD：99904113】

Program Terminal
【Pro CMD：99904112】

Set Terminal as 0x0D,0x0A and Enable Sending
【Pro CMD：99904114】

Example

Program a Windows OS general line feed and carrage returen as terminal

1. Read "Code Programming ON"
2. Read "Program Terminal"
3. Read "Set Terminal as 0x0D,0x0A and Enable Sending"
4. Read "Save "
5. Read "Code Programming OFF"
6. Read "Allow Terminal" to enable above programming. A line feed will appear to the right of a barcode.

Symbols

Introduction

Each type of barcode has its unique attribute. With the programming code, the engine will adjust to the changes of these attributes. Disabling reading of the symbols which do not apply will improve reading performance.

Code Programming ON

Load Factory Default

Code Programming OFF

Load Code 128 Factory Default
【Pro CMD：99910000】

Enable/Disable Code 128

Enable Code 128
【Pro CMD：99910002】

Disable Code 128
【Pro CMD：99910001】

TIPS

When the engine can not read Code 128, please read “Enable Code 128” and try again.

Code 128 Code ID

Code ID Setting
【Pro CMD：99910005】

Example

Example of setting Code 128 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Code 128 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Select Message Length

It is used to program the valid reading length of Code 128. The engine will send an error beep, if the decoded data length does not match the valid length.

Code 128 Message Length is defined by “Min. Message Length” and “Max. Message Length”.

Min Message Length
【Pro CMD：99910003】

Max Message Length
【Pro CMD：99910004】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of Code 128 to 8 bytes and Max Message Length to 12 bytes, read these programming codes

1、“Code Programming ON”
2、“Select Min Message Length”
3、Digit Code “8”, see Digit Code
4、“Save Programming”, see Digit Code
5、“Select Max Message Length”
6、Digit Code “1”
7、Digit Code “2”
8、“Save Programming”
9、“Code Programming OFF”

Code Programming ON

Load Factory Default

Load UCC/EAN-128 Factory Default
【Pro CMD：99910100】

Code Programming OFF

Enable/Disable UCC/EAN-128

Enable UCC/EAN-128
【Pro CMD：99910102】

Disable UCC/EAN-128
【Pro CMD：99910101】

TIPS

When the engine can not read UCC/EAN-128, please read “Enable UCC/EAN-128” and try again.

UCC/EAN-128 Code ID

Code ID Setting
【Pro CMD：99910105】

Example

Example of setting UCC/EAN-128 Code ID to “p” (0x70)

1. Read Enable Code Programming barcode.
2. Read UCC/EAN-128 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Select Message Length

It is used to program the valid reading length of UCC/EAN-128. The engine will send an error beep, if the decoded data length does not match the valid length.

UCC/EAN-128 Message Length is defined by “Min. Message Length” and “Max. Message Length”.

Min Message Length
【Pro CMD：99910103】

Max Message Length
【Pro CMD：99910104】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of UCC/EAN-128 to 8 bytes and Max Message Length to 12 bytes, read these programming codes

1、“Code Programming ON”
2、“Select Min Message Length”
3、Digit Code “8”, see Digit Code
4、“Save Programming”, see Digit Code
5、“Select Max Message Length”
6、Digit Code “1”
7、Digit Code “2”
8、“Save Programming”
9、“Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load AIM 128 Factory Default
【Pro CMD：99910200】

Enable/Disable AIM 128

Enable AIM 128
【Pro CMD：99910202】

Disable AIM 128
【Pro CMD：99910201】

TIPS

When the engine can not read AIM 128, please read “Enable AIM 128” and try again.

AIM 128 Code ID

Code ID Setting
【Pro CMD：99910205】

Example

Example of setting AIM 128 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read AIM 128 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Select Message Length

It is used to program the valid reading length of AIM 128. The engine will send an error beep, if the decoded data length does not match the valid length.

AIM 128 Message Length is defined by “Min. Message Length” and “Max. Message Length”.

Min Message Length
【Pro CMD：99910203】

Max Message Length
【Pro CMD：99910204】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of AIM 128 to 8 bytes and Max Message Length to 12 bytes, read these programming codes

1、“Code Programming ON”
2、“Select Min Message Length”
3、Digit Code “8”, see Digit Code
4、“Save Programming”, see Digit Code
5、“Select Max Message Length”
6、Digit Code “1”
7、Digit Code “2”
8、“Save Programming”
9、“Code Programming OFF”

EAN-8

Tools

Code Programming ON

Load Factory Default

Code Programming OFF

Load EAN-8 Factory Default
【Pro CMD：99910400】

Enable/Disable EAN-8

Enable EAN-8
【Pro CMD：9991402】

Disable EAN-8
【Pro CMD：99910401】

TIPS

When the engine can not read EAN-8, please read “Enable EAN-8” and try again.

EAN-8 Code ID

Code ID Setting
【Pro CMD：99910416】

Example

Example of setting EAN-8 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read EAN-8 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

2 Digits Addenda Code

2 Digits Addenda Code is the one to the right of an ordinary code.

Disable 2 Digits Addenda Code
【Pro CMD：99910405】

Only Read With 2 digits Addenda Code
【Pro CMD：99910407】

Enable 2 Digits Addenda Code
【Pro CMD：99910406】

5 Digits Addenda Code

5 Digits Addenda Code is the one to the right of an ordinary code.

Disable 5 Digits Addenda Code
【Pro CMD：99910410】

Only Read With 5 digits Addenda Code
【Pro CMD：99910412】

Enable 5 Digits Addenda Code
【Pro CMD：99910411】

“ Enable 2 Digits Addenda Code “ — read an ordinary code and 2 digits Addenda Code.
“Disable 2 Digits Addenda Code “ — read an ordinary code only, and ignore 2 digits Addenda Code.
“ Only Read With 2 digits Addenda Code “ — read 2 digits Addenda Code and only read code with 2 digits Addenda Code.

Code Programming ON

Code Programming OFF

EAN-8 expand to EAN-13

“ Do Not Expand to EAN-13 “ — keep original type and digits, do not expand.

“Expand to EAN-13 by Adding Leading 0s “ — expand to EAN-13 but keep code type.

“ Expand Message and Convert to EAN-13 “ — expand code digits and convert code type.

Do Not Expand to EAN-13
【Pro CMD：99910413】

Expand Message and Convert to EAN-13
【Pro CMD：99910415】

Expand to EAN-13 by Adding Leading 0s
【Pro CMD：99910414】

Check Digit

EAN-8 is fixed 8 digits barcode and the last digit is check digit. Check digit is a value caculated from all digits. It is used for checking if the all 8 digits are right.

Transmit Check
【Pro CMD：99910404】

Do Not Transmit Check
【Pro CMD：99910403】

Code Programming ON

Load Factory Default

Code Programming OFF

Load EAN-13 Factory Default
【Pro CMD：99910500】

Disable/Enable EAN-13

Enable EAN-13
【Pro CMD：99910502】

Disable EAN-13
【Pro CMD：99910501】

TIPS

When the engine can not read EAN-13, please read “Enable EAN-13” and try again.

Code Programming ON

Check Digit

EAN-13 is fixed 13 digits barcode and the last digit is check digit. Check digit is a value caculated from all digits. It is used for checking if the all 13 digits are right.

Code Programming OFF

Transmit Check
【Pro CMD：99910504】

Do Not Transmit Check
【Pro CMD：99910503】

EAN-13 Code ID

Code ID Setting
【Pro CMD：99910513】

Example

Example of setting EAN-13 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read EAN-13 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

2 Digits Addenda Code

2 Digits Addenda Code is the one to the right of an ordinary code.

Disable 2 Digits Addenda Code
【Pro CMD：99910505】

Only Read With 2 digits Addenda Code
【Pro CMD：99910507】

Enable 2 Digits Addenda Code
【Pro CMD：99910506】

5 Digits Addenda Code

5 Digits Addenda Code is the one to the right of an ordinary code.

Disable 5 Digits Addenda Code
【Pro CMD：99910510】

Only Read With 5 digits Addenda Code
【Pro CMD：99910512】

Enable 5 Digits Addenda Code
【Pro CMD：99910511】

“ Enable 2 Digits Addenda Code “ — read an ordinary code and 2 digits Addenda Code.
“Disable 2 Digits Addenda Code “ — read an ordinary code only, and ignore 2 digits Addenda Code.
“ Only Read With 2 digits Addenda Code “ — read 2 digits Addenda Code and only read code with 2 digits Addenda Code.

Code Programming ON

Load Factory Default

Code Programming OFF

Load ISSN Factory Default
【Pro CMD：99910600】

Enable/Disable ISSN

Enable ISSN
【Pro CMD：99910602】

Disable ISSN
【Pro CMD：99910601】

TIPS When the engine can not read ISSN, please read “Enable ISSN” and try again.

ISSN Code ID

Code ID Setting
【Pro CMD：99910603】

Example

Example of setting ISSN Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read ISSN Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Load Factory Default

Code Programming OFF

Load ISBN Factory Default
【Pro CMD：99910700】

Enable/Disable ISBN

Enable ISBN
【Pro CMD：99910702】

Disable ISBN
【Pro CMD：99910701】

TIPS

When the engine can not read ISBN, please read “Enable ISBN” and try again.

Code Programming ON

Code Programming OFF

ISBN Digits

Use 13 Digits
【Pro CMD：99910704】

Use 10 Digits
【Pro CMD：99910703】

ISBN Code ID

Code ID Setting
【Pro CMD：99910705】

Example

Example of setting ISBN Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read ISBN Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Load Factory Default

Code Programming OFF

Load UPC-E Factory Default
【Pro CMD：99911000】

Disable/Enable UPC-E

Enable UPC-E
【Pro CMD：99911002】

Disable UPC-E
【Pro CMD：99911001】

TIPS
When the engine can not read UPC-E, please read “Enable UPC-E” and try again.

Code Programming ON

Check Digit

UPC-E is fixed 8 digits barcode and the last digit is check digit. Check digit is a value caculated from all digits. It is used for checking if the all 8 digits are right.

Code Programming OFF

Transmit Check
【Pro CMD：99911004】

Do Not Transmit Check
【Pro CMD：99911003】

UPC-E Code ID

Code ID Setting
【Pro CMD：99911020】

Example

Example of setting UPC-E Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read UPC-E Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

2 Digits Addenda Code

2 Digits Addenda Code is the one to the right of an ordinary code.

Disable 2 Digits Addenda
【Pro CMD：99911005】

Only Read With 2 digits Addenda Code
【Pro CMD：99911007】

Enable 2 Digits Addenda Code
【Pro CMD：99911006】

5 Digits Addenda Code

5 Digits Addenda Code is the one to the right of an ordinary code.

Disable 5 Digits Addenda Code
【Pro CMD：99911010】

Only Read With 5 digits Addenda Code
【Pro CMD：99911012】

Enable 5 Digits Addenda Code
【Pro CMD：99911011】

TIPS

“ Enable 2 Digits Addenda Code “ — read an ordinary code and 2 digits Addenda Code.
“Disable 2 Digits Addenda Code “ — read an ordinary code only, and ignore 2 digits Addenda Code.
“ Only Read With 2 digits Addenda Code “ — read 2 digits Addenda Code and only read code with 2 digits Addenda Code.

Code Programming ON

Code Programming OFF

Transmit Default “0”

The first byte of UPC-E is default to “0”.

Do Not Transmit “0”
【Pro CMD：99911013】

Transmit “0”
【Pro CMD：99911014】

UPC-E Expand to UPC-A

“ Do Not Expand “ — keep original type and digits, do not expand.

“Expand to UPC-A “ — expand to UPC-A but keep code type.

“ Expand Message and Convert to UPC-A “ — expand code digits and convert code type.

Do Not Expand
【Pro CMD：99911015】

Expand Message and Convert to UPC-A
【Pro CMD：99911017】

Expand to UPC-A
【Pro CMD：99911016】

Code Programming ON

Load Factory Default

Code Programming OFF

Load UPC-A Factory Default
【Pro CMD：99911100】

Disable/Enable UPC-A

Enable UPC-A
【Pro CMD：99911102】

Disable UPC-A
【Pro CMD：99911101】

TIPS When the engine can not read UPC-A, please read “Enable UPC-A” and try again.

UPC-A Code ID

Code ID Setting
【Pro CMD：99911115】

Example

Example of setting UPC-A Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read UPC-A Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Check Digit

UPC-A is fixed 13 digits barcode and the last digit is check digit. Check digit is a value caculated from all digits. It is used for checking if the all 13 digits are right.

Code Programming OFF

Transmit Check
【Pro CMD：99911104】

Do Not Transmit Check
【Pro CMD：99911103】

Transmit Default “0”

The first byte of UPC-A is default to “0”.

Do Not Transmit “0”
【Pro CMD：99911113】

Transmit “0”
【Pro CMD：99911114】

Code Programming ON

Code Programming OFF

2 Digits Addenda Code

2 Digits Addenda Code is the one to the right of an ordinary code.

Disable 2 Digits Addenda Code
【Pro CMD：99911105】

Only Read With 2 digits Addenda Code
【Pro CMD：99911107】

Enable 2 Digits Addenda Code
【Pro CMD：99911106】

5 Digits Addenda Code

5 Digits Addenda Code is the one to the right of an ordinary code.

Disable 5 Digits Addenda Code
【Pro CMD：99911110】

Only Read With 5 digits Addenda Code
【Pro CMD：99911112】

Enable 5 Digits Addenda Code
【Pro CMD：99911111】

TIPS

“ Enable 2 Digits Addenda Code “ — read an ordinary code and 2 digits Addenda Code.
“Disable 2 Digits Addenda Code “ — read an ordinary code only, and ignore 2 digits Addenda Code.
“ Only Read With 2 digits Addenda Code “ — read 2 digits Addenda Code and only read code with 2 digits Addenda Code.

Code Programming ON

Load Factory Default

Code Programming OFF

Load Interleaved 2 of 5 Factory Default
【Pro CMD：99911200】

Disable/Enable Interleaved 2 of 5

Enable Interleaved 2 of 5
【Pro CMD：99911202】

Disable Interleaved 2 of 5
【Pro CMD：99911201】

TIPS

When the engine can not read Interleaved 2 of 5, please read “Enable Interleaved 2 of 5” and try again

Interleaved 2 of 5 Code ID

Code ID Setting
【Pro CMD：99911210】

Example

Example of setting Interleaved 2 of 5 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Interleaved 2 of 5 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

Interleaved 2 of 5 may include Check Digit (not compulsory) following its barcode messages. If included, it could be the last digit. It verifies the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmit barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmit all messages; if not, engine sends an error beep.

“NO Check, Transmit All”
【Pro CMD：99911203】

Check, Do Not Transmit Check Digit
【Pro CMD：99911204】

Check, Transmit All
【Pro CMD：99911205】

When “Check, Do Not Transmit Check digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include check Digit) Interleaved 2 of 5 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check digit” enabled leads to error beep.

Code Programming ON

Select Message Length

Code Programming OFF

It is used to program the valid reading length of Interleaved 2 of 5. The engine will send an error beep, if the decoded data length does not match the valid length.

Interleaved 2 of 5 Message Length is defined by “Min. Message Length” and “Max. Message Length”

Min Message Length
【Pro CMD：99911206】

Max Message Length
【Pro CMD：99911207】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of Interleaved 2 of 5 as 8 bytes, and Max Message length as 12 bytes, read these programming codes:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code Appendix (Pxxx)
4. “Save Programming”, see Digit Code Appendix (Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Code Programming OFF

ITF-6 is a fixed length 6 bytes Interleaved 2 of 5 barcode with check digit.
When enabled, ITF-6 precedes 6-byte Interleaved 2 of 5 barcode.

Load ITF-6 Factory Default
【Pro CMD：99911300】

Disable ITF-6 User Selection
【Pro CMD：99911301】

Enable ITF-6, Do Not Transmit Check Digit
【Pro CMD：99911302】

Enable ITF-6, Transmit Check Digit
【Pro CMD：99911303】

For instance, when ITF-6 is enabled and Interleaved 2 of 5 is disabled, the ITF-6 and 6 bytes Interleaved 2 of 5 with check digit can be read, but other Interleaved 2 of 5 can not.

ITF-6 Code ID

Code ID Setting
【Pro CMD：99911304】

Example

Example of setting ITF-6 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read ITF-6 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

ITF-14 is a fixed length of 14 bytes Interleaved 2 of 5 barcode with Check digit. By factory default, it is disabled.

When enabled, ITF-14 precedes 14-byte Interleaved 2 of 5 barcode.

Code Programming OFF

Load ITF-14 Factory Default
【Pro CMD：99911400】

Enable ITF-14, Do Not Transmit Check Digit
【Pro CMD：99911402】

Disable ITF-14
【Pro CMD：99911401】

Enable ITF-14, Transmit Check Digit
【Pro CMD：99911403】

For instance, when ITF-14 is enabled and Interleaved 2 of 5 is disabled, the ITF-14 and 14 bytes Interleaved 2 of 5 with check digit can be read, but other Interleaved 2 of 5 can not. If the programming of ITF-14 violates the one of Deutsche 14, ITF-14 precedes Deutsche 14.

ITF-14 Code ID

Code ID Setting
【Pro CMD：99911404】

Example

Example of setting ITF-14 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read ITF-14 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Load Factory Default

Code Programming OFF

Load **Deutshe14 Factory Default**
【Pro CMD：99911500】

Disable/Enable Deutshe14

Enable Deutshe14，Do Not Transmit Check Digit
【Pro CMD：99911502】

Disable Deutshe14
【Pro CMD：99911501】

Enable Deutshe14， Transmit Check Digit
【Pro CMD：99911503】

TIPS

When the engine can not read Deutshe14, please read “Enable Deutshe14” and try again
If Deutsche 14 and ITF-14 are enabled at the same time, the engine may mis-decode or has chaos in programming. So it is better to disable ITF-14 if not used.

Deutshe14 Code ID

Code ID Setting
【Pro CMD：99911504】

Example

Example of setting Deutshe14 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Deutshe14 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Load Factory Default

Code Programming OFF

Load **Deutshe12 Factory Default**
【Pro CMD：99911600】

Disable/Enable Deutshe12

Enable Deutshe12，Do Not Transmit Check Digit
【Pro CMD：99911602】

Disable Deutshe12
【Pro CMD：99911601】

Enable Deutshe12， Transmit Check Digit
【Pro CMD：99911603】

TIPS

When the engine can not read Deutshe12, please read “Enable Deutshe12” and try again. If Deutsche 12 and ITF-12 are enabled at the same time, the engine may mis-decode or has chaos in programming. So it is better to disable ITF-14 if not used.

Deutshe12 Code ID

Code ID Setting
【Pro CMD：99911604】

Example

Example of setting Deutshe12 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Deutshe12 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Load Factory Default

Code Programming OFF

Load COOP25 Factory Default
【Pro CMD：99911700】

Enable/ Disable COOP25

Enable COOP25
【Pro CMD：99911702】

Disable COOP25
【Pro CMD：99911701】

TIPS

When the engine can not read COOP25, please read “Enable COOP25” and try again.

COOP25（Japanese Matrix 25） Code ID

Code ID Setting
【Pro CMD：99911710】

Example

Example of setting COOP25（Japanese Matrix 25） Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read COOP25（Japanese Matrix 25） Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

COOP25 may include Check Digit (not compulsory) following its barcode messages. If included, it may be the last digit. It verifies the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

NO Check, Transmit All
【Pro CMD：99911703】

Check, Transmit All
【Pro CMD：99911704】

Check, Do Not Transmit Check Digit
【Pro CMD：99911705】

When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include Check Digit) COOP25 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.

Code Programming ON

Code Programming OFF

Select Message Length

It is used to program the valid reading length of COOP25. The engine will send an error beep, if the decoded data length does not match the valid length. COOP25 Message Length is defined by “Min. Message Length” and “Max. Message Length”.

Min Message Length
【Pro CMD：99911706】

Max Message Length
【Pro CMD：99911707】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of COOP25 to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load Matrix 25 Factory Default
【Pro CMD：99912000】

Enable/ Disable Matrix 25

Enable Matrix 25
【Pro CMD：99912002】

Disable Matrix 25
【Pro CMD：99912001】

TIPS

When the engine can not read Matrix 25, please read “Enable Matrix 25” and try again.

Matrix 25 Code ID

Code ID Setting
【Pro CMD：99912010】

Example

Example of setting Matrix 25 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Matrix 25 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

Matrix 25 may include Check Digit (not compulsory) following its barcode messages. If included, it may be the last digit. It verifies the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

NO Check, Transmit All
【Pro CMD：99912003】

Check, Transmit All
【Pro CMD：99912004】

Check, Do Not Transmit Check Digit
【Pro CMD：99912005】

When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include Check Digit) Matrix 25 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.

Code Programming ON

Select Message Length

It is used to program the valid reading length of Matrix 25. The engine will send an error beep, if the decoded data length does not match the valid length. Matrix 25 Message Length is defined by “Min. Message Length” and “Max. Message Length”.

Code Programming OFF

Min Message Length
【Pro CMD：99912006】

Max Message Length
【Pro CMD：99912007】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of Matrix 25 to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load Industrial 25 Factory Default
【Pro CMD：99912100】

Enable/ Disable Industrial 25

Enable Industrial 25
【Pro CMD：99912102】

Disable Industrial 25
【Pro CMD：99912101】

TIPS

When the engine can not read Industrial 25, please read “Enable Industrial 25” and try again.

Industrial 25 Code ID

Code ID Setting
【Pro CMD：99912110】

Example

Example of setting Industrial 25 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Industrial 25 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

Industrial 25 may include Check Digit (not compulsory) following its barcode messages. If included, it may be the last digit. It verifies the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

NO Check, Transmit All
【Pro CMD：99912103】

Check, Transmit All
【Pro CMD：99912104】

Check, Do Not Transmit Check Digit
【Pro CMD：99912105】

When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include Check Digit) Industrial 25 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.

Code Programming ON

Code Programming OFF

Select Message Length

It is used to program the valid reading length of Industrial 25. The engine will send an error beep, if the decoded data length does not match the valid length.

Industrial 25 Message Length is defined by “Min. Message Length” and “Max. Message Length”.

Min Message Length
【Pro CMD：99912106】

Max Message Length
【Pro CMD：99912107】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of Industrial 25 to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load Standard 25 Factory Default
【Pro CMD：99912200】

Enable/ Disable Standard 25

Enable Standard 25
【Pro CMD：99912202】

Disable Standard 25
【Pro CMD：99912201】

TIPS

When the engine can not read Standard 25, please read “Enable Standard 25” and try again.

Standard 25 Code ID

Code ID Setting
【Pro CMD：99912210】

Example

Example of setting Standard 25 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Standard 25 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

Standard 25 may include Check Digit (not compulsory) following its barcode messages. If included, it may be the last digit. It verifies the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

NO Check, Transmit All
【Pro CMD：99912203】

Check, Transmit All
【Pro CMD：99912204】

Check, Do Not Transmit Check Digit
【Pro CMD：99912205】

When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include Check Digit) Standard 25 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.

Code Programming ON

Code Programming OFF

Select Message Length

It is used to program the valid reading length of Standard 25. The engine will send an error beep, if the decoded data length does not match the valid length.

Standard 25 Message Length is defined by “Min. Message Length” and “Max. Message Length ”.

Min Message Length
【Pro CMD：99912206】

Max Message Length
【Pro CMD：99912207】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of Standard 25 to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load Code 39 Factory Default
【Pro CMD：99912400】

Enable/Disable Code 39

Enable Code 39
【Pro CMD：99912402】

Disable Code 39
【Pro CMD：99912401】

TIPS When the engine can not read Code 39, please read “Enable Code 39” and try again

Code 39 Code ID

Code ID Setting
【Pro CMD：99912414】

Example

Example of setting Code 39 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Code 39 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

Code 39 may include Check Digit (not compulsory) following its barcode message. It verifies the barcode message.

» "NO Check, Transmit All" means to read without check and transmit all bytes including barcode message and Check Digit.

» "Check, Do Not Transmit Check Digit" means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» "Check, Transmit All" means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

NO Check, Transmit All
【Pro CMD：99912403】

Check, Transmit All
【Pro CMD：99912405】

Check, Do not transmit Check Digit
【Pro CMD：99912404】

When “Check, Do not Transmit Check digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include check byte) Code 39 with the Min Message Length being 4 bytes and “Check, Do not transmit Check Digit” enabled leads to error beep.

Code Programming ON

Code Programming OFF

Transmit Start & Stop Character

Code 39 has one "*" before and another after digits as Start & Stop Character. Transmission of “*” can be selected.

Transmit Both “*”
【Pro CMD：99912407】

Transmit Neither “*”
【Pro CMD：99912406】

Decode ASCII

Code 39 can include full ASCII characters. For factory default, the engine only decodes part of them. Read “Enable Full ASCII decode” to decode full ASCII characters.

Partial ASCII Decode
【Pro CMD：99912410】

Full ASCII Decode
【Pro CMD：99912411】

Code Programming ON

Code Programming OFF

Select Message Length

Code 39 Message Length is defined by “Min. Message Length” and “Max. Message Length “.It is used to program the valid reading length of Code 39. The engine will send an error beep, if the decoded data length does not match the valid length.

Min Message Length
【Pro CMD：99912412】

Max Message Length
【Pro CMD：99912413】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of Code 39 to 8 bytes, and Max Message Length to 12 bytes, read these programming codes:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load Codabar Factory Default
【Pro CMD：99912500】

Enable/Disable Codabar

Enable Codabar
【Pro CMD：99912502】

Disable Codabar
【Pro CMD：99912501】

TIPS

When the engine can not read Codabar, please read “Enable Codabar” and try again.

Codabar Code ID

Code ID Setting
【Pro CMD：99912516】

Example

Example of setting Codabar Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Codabar Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

Codabar may include Check Digit (not compulsory) following its barcode message. It verifies the barcode message.

» "NO Check, Transmit All" means to read without check and transmit all bytes including barcode message and Check Digit.

» "Check, Do Not Transmit Check Digit" means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» "Check, Transmit All" means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

NO Check, Transmit All
【Pro CMD：99912503】

Check, Transmit All
【Pro CMD：99912504】

Check, Do not transmit Check Digit
【Pro CMD：99912505】

When “Check, Do not Transmit Check digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include check byte) Codabar with the Min Message Length being 4 bytes and “Check, Do not transmit Check Digit” enabled leads to error beep.

Code Programming ON

Code Programming OFF

Transmit Start & Stop Character

Do Not Transmit Both Start & Stop Character
【Pro CMD：99912506】

Transmit Both Start & Stop Character
【Pro CMD：99912507】

Use ABCD/ABCD As Start & Stop Character
【Pro CMD：99912510】

Use ABCD/TN*E As Start & Stop Character
【Pro CMD：99912511】

Use abcd/abcd As Start & Stop Character
【Pro CMD：99912512】

Use abcd/tn*e As Start & Stop Character
【Pro CMD：99912513】

Code Programming ON

Code Programming OFF

Select Message Length

Codabar Message Length is defined by “Min. Message Length” and “Max. Message Length “.It is used to program the valid reading length of Codabar. The engine will send an error beep, if the decoded data length does not match the valid length.

Min Message Length
【Pro CMD：99912514】

Max Message Length
【Pro CMD：99912515】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of Codabar to 8 bytes, and Max Message Length to 12 bytes, read these programming codes:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load Code 93 Factory Default
【Pro CMD：99912600】

Enable /Disable Code 93

Enable Code 93
【Pro CMD：99912602】

Disable Code 93
【Pro CMD：99912601】

TIPS

When the engine can not read Code 93, please read “Enable Code 93” and try again.

Code 93 Code ID

Code ID Setting
【Pro CMD：99912610】

Example

Example of setting Code 93 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Code 93 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

Code 93 may include Check Digits (not compulsory) following its barcode message. If included, they are the last two digits. They verifie the barcode message.

» "NO Check, Transmit All" means to read without check and transmit all bytes including barcode message and Check Digit.

» "Check, Do Not Transmit Check Digit" means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» "Check, Transmit All" means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

NO Check, Transmit All
【Pro CMD：99912603】

Check, Transmit All
【Pro CMD：99912605】

Check, Do not transmit Check Digit
【Pro CMD：99912604】

When “Check, Do not Transmit Check digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include check byte) Code 93 with the Min Message Length being 4 bytes and “Check, Do not transmit Check Digit” enabled leads to error beep.

Code Programming ON

Code Programming OFF

Select Message Length

It is used to program the valid reading length of Code 93. The engine will send an error beep, if the decoded data length does not match the valid length.
Code 93 Message Length is defined by “Min. Message Length” and “Max. Message Length .”

Min Message Length
【Pro CMD：99912606】

Max Message Length
【Pro CMD：99912607】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of Code 93 to 8 bytes and Max Message Length to 12 bytes, read these programming codes:
1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load Code 11 Factory Default
【Pro CMD：99912700】

Enable/ Disable Code 11

Enable Code 11
【Pro CMD：99912702】

Disable Code 11
【Pro CMD：99912701】

TIPS

When the engine can not read Code 11, please read “Enable Code 11” and try again.

Code 11 Code ID

Code ID Setting
【Pro CMD：99912715】

Example

Example of setting Code 11 Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Code 11 Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

Code 11 may include Check Digit (not compulsory) following its barcode messages. If included, it may be the last one or two digits. It verifies the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

No Check
【Pro CMD：99912703】

Single Check Digit，MOD11
【Pro CMD：99912704】

Double Check Digits, MOD11/MOD11
【Pro CMD：99912705】

Double Check Digits, MOD11/MOD9
【Pro CMD：99912706】

Single Check Digit MOD11（Len <= 10）
Double Check Digits MOD11/
MOD11 （Len > 10）
【Pro CMD：99912707】

Single Check Digit MOD11 （Len <= 10）
Double Check Digits MOD11/
MOD9 （Len > 10）
【Pro CMD：99912710】

Do not transmit Check Digit
【Pro CMD：99912711】

Transmit Check Digit
【Pro CMD：99912712】

When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include Check Digit) Code 11 with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.

Code Programming ON

Code Programming OFF

Select Message Length

It is used to program the valid reading length of Code 11. The engine will send an error beep, if the decoded data length does not match the valid length.

Code 11 Message Length is defined by “Min. Message Length” and “Max. Message Length”.

Min Message Length
【Pro CMD：99912713】

Max Message Length
【Pro CMD：99912714】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of Code 11 to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load Plessey Factory Default
【Pro CMD：99913000】

Enable/ Disable Plessey

Enable Plessey
【Pro CMD：99913002】

Disable Plessey
【Pro CMD：99913001】

TIPS

When the engine can not read Plessey, please read “Enable Plessey” and try again.

Plessey Code ID

Code ID Setting
【Pro CMD：99913010】

Example

Example of setting Plessey Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read Plessey Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

Plessey may include Check Digits (not compulsory) following its barcode messages. If included, they are the last two digit. They verifie the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

» “Check, Do Not Transmit Check Digit” means to read and check. If verification is successful, transmits barcode message; if not, engine sends an error beep.

» “Check, Transmit All” means to read and check. If verification is successful, transmits all messages; if not, engine sends an error beep.

NO Check, Transmit All
【Pro CMD：99913003】

Check, Transmit All
【Pro CMD：99913004】

Check, Do not transmit Check Digit
【Pro CMD：99913005】

When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include Check Digit) Plessey with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.

Code Programming ON

Code Programming OFF

Select Message Length

It is used to program the valid reading length of Plessey. The engine will send an error beep, if the decoded data length does not match the valid length.

Plessey Message Length is defined by “Min. Message Length” and “Max. Message Length”.

Min Message Length
【Pro CMD：99913006】

Max Message Length
【Pro CMD：99913007】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of Plessey to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load MSI-Plessey Factory Default
【Pro CMD：99913100】

Enable/ Disable MSI-Plessey

Enable MSI-Plessey
【Pro CMD：99913102】

Disable MSI-Plessey
【Pro CMD：99913101】

TIPS

When the engine can not read MSI-Plessey, please read “Enable MSI-Plessey” and try again.

MSI-Plessey Code ID

Code ID Setting
【Pro CMD：99913113】

Example

Example of setting MSI-Plessey Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read MSI-Plessey Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Code Programming ON

Code Programming OFF

Check Digit

MSI-Plessey may include Check Digit (not compulsory) following its barcode messages. If included, it may be the last one or two digits. It verifies the barcode message.

» “NO Check, Transmit All” means to read without check and transmit all bytes including barcode message and Check Digit.

No Check
【Pro CMD：99913103】

Single Check Digit，MOD10
【Pro CMD：99913104】

Double Check Digits, MOD10/MOD10
【Pro CMD：99913105】

Double Check Digits, MOD10/MOD11
【Pro CMD：99913106】

Do not transmit Check Digit
【Pro CMD：99913107】

Transmit Check Digit
【Pro CMD：99913110】

When “Check, Do Not Transmit Check Digit” is enabled and barcode message length minus one is less than Min Message Length, it will lead to error beep.
E.g.：Reading a 4-byte (include Check Digit) MSI-Plessey with the Min Message Length being 4 bytes and “Check, Do Not Transmit Check Digit” enabled leads to error beep.

Code Programming ON

Select Message Length

MSI-Plessey Message Length is defined by “Min. Message Length” and “Max. Message Length”.It is used to program the valid reading length of MSI-Plessey. The engine will send an error beep, if the decoded data length does not match the valid length.

Code Programming OFF

Min Message Length
【Pro CMD：99913111】

Max Message Length
【Pro CMD：99913112】

TIPS

1D bar code Message Length should not exceed 255 bytes. If Max Message Length is less than Min Message Length, it means the engine will only support barcodes of the two lengths. If Max Message Length is equal to Min Message Length, the engine will only support barcodes of the length.

Example

To set Min Message Length of MSI-Plessey to 8 bytes and the Max Message Length to 12 bytes. Read these programming code:

1. “Code Programming ON”
2. “Select Min Message Length”
3. Digit Code “8”, see Digit Code (Appendix Pxxx)
4. “Save Programming”, see Digit Code (Appendix Pxxx)
5. “Select Max Message Length”
6. Digit Code “1”
7. Digit Code “2”
8. “Save Programming”
9. “Code Programming OFF”

Code Programming ON

Load Factory Default

Code Programming OFF

Load GS1 Databar Factory Default
【Pro CMD：99913200】

Enable/ Disable GS1 Databar

Enable GS1 Databar
【Pro CMD：99913202】

Disable GS1 Databar
【Pro CMD：99913201】

TIPS

When the engine can not read GS1 Databar, please read “Enable GS1 Databar” and try again.

GS1 Databar Code ID

Code ID Setting
【Pro CMD：99913203】

Example

Example of setting GS1 Databar Code ID to “p” (0x70)
1. Read Enable Code Programming barcode.
2. Read GS1 Databar Code ID Setting barcode.
3. Read Following Barcodes: “7”, and “0”
4. Read Save barcode
5. Read Disable Code Programming barcode.

Factory Default List

Parameters	Factory Default	Remark
General Programming		
Code Programming	On	
Send Pro Code Value	Off	
Working Mode	Hand-held Mode	
Reading a Barcode Time Length	15s	Range：0-15s， 0 is infinite time.
Interval Length	1s	Range：0-7.5s
Sensitivity	High Sensitivity	Enabled in Sensor Mode
Security Level	Level 1	
Beeper	Medium Frequency & Loud Volume, 150ms sound length	Beeper for a successful reading
Reading Same Barcode	Off	Enabled in Auto Mode
Restart Timer After a valid Reading	On	Enabled in Auto Mode
Communication Programming		
Baud Rate	9600	
Serial Port Check	No Check	
Stop Digit	1 Digit	Fixed
Flow Controlling	Off	Fixed
Data Bit	8 Bit	
USB Virtual Keyboard	On	
Virtual Keyboard Layout	No. 0 Chinese	
Character Delay	0ms	0~150ms
Character Conversion	Constant	
Caps Lock	Off	
Nums Lock	Off	
Scroll Lock	Off	
Data Format Programming		
Prefix Sequences	CodeID+User Prefix+AIMID	CodeID+Prefix+(AIMID+Data) +Suffix+Terminal
AIMID	Off	]Cm Mark
CodeID	Off	One or two Digit， Capital or Small Letter
User Prefix	Off	No more than 11 digits
User Suffix	Off	No more than 11 digits
Terminal	Off	No more than 7 digits

Parameters	Factory Default	Remark
Symbol		
Code 128		
Enable	On	
Max Message Length	255	
Min Message Length	1	
UCC/EAN-128		
Enable	On	
Max Message Length	255	
Min Message Length	1	
AIM 128		
Enable	Off	
Min Message Length	1	
EAN-8		
Enable	On	
Send Check Digit	On	
Enable 2 Digits Addenda Code	Off	
Enable 5 Digits Addenda Code	Off	
Only Read With 2 digits Addenda Code	Off	
Only Read With 5 digits Addenda Code	Off	
Expand to EAN-13	Off	
Expand and Change Type to EAN-13	Off	
EAN-13		
Enable	On	
Send Check Digit	On	
Enable 2 Digits Addenda Code	Off	
Enable 5 Digits Addenda Code	Off	
Only Read With 2 digits Addenda Code	Off	
Only Read With 5 digits Addenda Code	Off	

ISSN		
Enable	Off	
ISBN		
Enable	Off	
Use 10 Digits	Off	
UPC-E		
Enable	On	
Send Check Digit	On	
Enable 2 Digits Addenda Code	Off	
Enable 5 Digits Addenda Code	Off	
Only Read With 2 digits Addenda Code	Off	
Only Read With 5 digits Addenda Code	Off	
Expand to UPC-A	Off	
Expand and Change Type to UPC-A	Off	
Send Default “0”	Off	
UPC-A		
Enable	On	
Send Check Digit	On	
Enable 2 Digits Addenda Code	Off	
Enable 5 Digits Addenda Code	Off	
Only Read With 2 digits Addenda Code	Off	
Only Read With 5 digits Addenda Code	Off	
Send Default “0”	Off	
Interleaved 2 of 5		
Enable	On	
Check	Off	
Send Check Digit	Off	
Max Message Length	255	
Min Message Length	6	No less than 4
ITF-6		
Enable	Off	
Send Check Digit	On	
ITF-14		
Enable	Off	
Send Check Digit	On	

Deutsche 14		
Enable	Off	
Send Check Digit	On	
Deutsche 12		
Enable	Off	
Send Check Digit	On	
COOP 25(Japanese Matrix 25)		
Enable	Off	
Check	Off	
Send Check Digit	Off	
Max Message Length	255	
Min Message Length	6	No less than 4
Matrix 25(European Matrix 25)		
Enable	On	
Check	Off	
Send Check Digit	Off	
Max Message Length	255	
Min Message Length	6	No less than 4
Industrial 25		
Enable	On	
Check	Off	
Send Check Digit	Off	
Max Message Length	255	
Min Message Length	6	No less than 4
Standard 25		
Enable	On	IATA 25
Check	Off	
Send Check Digit	Off	
Max Message Length	255	
Min Message Length	6	No less than 4
Code 39		
Enable	On	
Check	Off	
Send Check Digit	Off	
Send Start & Stop Character	On	

Support Full ASCII	On	
Max Message Length	255	
Min Message Length	4	No less than 4 (including Start & Stop Character)
Codabar		
Enable	On	
Check	Off	
Send Check Digit	Off	
Send Start & Stop Character	On	
ABCD/ABCD as Start & Stop Character	On	Choose 1 In 4
ABCD/TN*E as Start & Stop Character	Off	
abcd/abcd as Start & Stop Character	Off	
abcd/tn*e as Start & Stop Character	Off	
Max Message Length	255	
Min Message Length	4	No less than 4
Code 93		
Enable	On	
Check	On	
Send Check Digit	Off	
Max Message Length	255	
Min Message Length	2	No less than 1
Code 11		
Enable	Off	
Send Check Digit	Off	
No Check	On	
1 Digit, MOD11 Check	Off	
2 Digits, MOD11/MOD11 Check	Off	
2 Digits, MOD11/MOD9 Check	Off	
Auto 2 Digits, MOD11/MOD11	Off	
Auto 2 Digits, MOD11/MOD9	Off	
Max Message Length	255	
Min Message Length	4	No less than 4
Plessey		
Enable	Off	
Check	Off	
Send Check Digit	Off	

Max Message Length	255	
Min Message Length	4	No less than 1
MSI-Plessey		
Enable	Off	
Send Check Digit	Off	
No Check	On	
1 Digit, MOD10 Check	Off	
2 Digits, MOD10/MOD10 Check	Off	
2 Digits, MOD10/MOD11 Check	Off	
Max Message Length	255	
Min Message Length	4	No less than 1
GS1 Databar		
Enable	On	
Max Message Length	255	
Min Message Length	1	

Symbol	AIM ID	Possible AIM ID Modifiers(m)
Code 128	]C0	
UCC/EAN-128	]C1	
AIM 128	]C2	
ISBT 128	]C4	
EAN-8	]E4	
EAN-13	]E0	
EAN-13 with Addon	]E3	
ISSN	]X0	
ISBN	]X0	
UPC-E	]E0	
UPC-E with Addon	]E3	
UPC-A	]E0	
UPC-A with Addon	]E3	
Interleaved 2 of 5	]Im	0,1,3
ITF-6	]Im	1,3
ITF-14	]Im	1,3
Deutsche 14	]X0	
Deutsche 12	]X0	
COOP 25（Japanese Matrix 25）	]X0	
Matrix 25(European Matrix 25)	]X0	
Industrial 25	]S0	
Standard 25	]R0	
Code 39	]Am	0,1,3,4,5,7
Codabar	]Fm	0,2,4
Code 93	]G0	
Code 11	]Hm	0,1,3
Plessey	]P0	
MSI-Plessey	]Mm	0,1
GS1 Databar	]e0	

Reference:

» ISO/IEC 15424:2008

» Information technology – Automatic identification and data capture techniques – Data Carrier Identifiers (including Symbology Identifiers)

Symbol	Code ID
Code 128	j
UCC/EAN-128	u
AIM 128	f
ISBT 128	t
EAN-8	g
EAN-13	d
ISSN	n
ISBN	B
UPC-E	h
UPC-A	c
Interleaved 2 of 5	e
ITF-6	r
ITF-14	q
Deutsche 14	w
Deutsche 12	l
COOP 25（Japanese Matrix 25）	o
Matrix 25(European Matrix 25)	v
Industrial 25	i
Standard 25	s
Code 39	b
Codabar	a
Code 93	y
Code 11	z
Plessey	p
MSI-Plessey	m
GS1 Databar	R

Digit Code

Tools

Code Programming ON

Code Programming OFF

It is must to read save after reading digit code.

0

【Pro CMD：99900000】

4

【Pro CMD：99900004】

1

【Pro CMD：99900001】

5

【Pro CMD：99900005】

2

【Pro CMD：99900002】

6

【Pro CMD：99900006】

3

【Pro CMD：99900003】

7

【Pro CMD：99900007】

Code Programming ON

Code Programming OFF

8
【Pro CMD：99900010】

9
【Pro CMD：99900011】

A
【Pro CMD：99900012】

B
【Pro CMD：99900013】

C
【Pro CMD：99900014】

D
【Pro CMD：99900015】

E
【Pro CMD：99900016】

F
【Pro CMD：99900017】

Code Programming ON

Code Programming OFF

In order to save the received data “Save” has to be read after data transition completed. If error occurs when reading data,
the wrong data can be deleted and the setting up can be done again..

Eg, after a program code is received then ‘1 2 3” in order is received, if then read “Abort One Data of Current Setting” the “3” will be deleted; if read “Abort One String of Current Setting” the ‘123’ will be deleted; if read “Abort Current Setting” both the program code and ‘123’ will be deleted, the device will be on status of “initiating program code”.

Save
【Pro CMD：99900020】

Abort One Data of Current Setting
【Pro CMD：99900021】

Abort Current Setting
【Pro CMD：99900023】

Abort All String of Current Setting
【Pro CMD：99900022】